

ELECTRONIC TUBE REFERENCE

TV9140

Specialized - Traveling Wave electronic tube

CONSOLIDATED TECHNICAL DATA

1 SECTION
CONSTRUCTION
TRAVELINGWAVE

Broadband pulsed traveling-wave amplifier covering approximately 2.8–3.15 GHz, delivering roughly 6–10 kW peak output with permanent-magnet focusing and grid-controlled beam switching.

GENERAL CHARACTERISTICS

BASE DESIGNATION	–	BASE PINS	–
NOMINAL HEATER	– / –	PARALLEL HEATER	– / –
HEATING	Indirect	SERIES OPERATION	Not specified
CATHODE ARRANGEMENT	Separate cathodes	SECTION CONSTRUCTION	Similar

SECTION RATINGS

SECTION1	TravelingWave
<i>No fixed ratings recorded.</i>	
<i>Published ratings and characteristics audited; detailed numeric data retained in parameter table.</i>	

The TV9140 is a broadband pulsed traveling-wave-tube amplifier delivering approximately 6 to 10 kW peak output from 2.8 to 3.15 GHz. It uses permanent-magnet focusing, grid-controlled beam switching, and forced-air cooling.

SOURCE OPERATING CONDITIONS

[SOURCE PDF](#)

1972 Thomson CSF

Published test conditions and operating points. Values on this page are preserved as reported by this source.

1972 THOMSON CSF

Section 1 · TravelingWave

OTHER		
PARAMETER	PUBLISHED VALUE	CONDITION / NOTE
The TV	9140	The TV 9140 is a traveling wave pulse amplifier
which delivers [1]	6	which delivers 6 to 10 kilowatts peak output between 2. 8
which delivers [2]	10	which delivers 6 to 10 kilowatts peak output between 2. 8
which delivers [3]	2	which delivers 6 to 10 kilowatts peak output between 2. 8
which delivers [4]	8	which delivers 6 to 10 kilowatts peak output between 2. 8
its	360 MHz	its 360 MHz bandwidth without adjustment for change of
Heatercurrentcvivemeennnnnn [1]	1.75 A	Heatercurrentcvivemeennnnnn. 1.75 - 2.25 A
Heatercurrentcvivemeennnnnn [2]	2.25 A	Heatercurrentcvivemeennnnnn. 1.75 - 2.25 A
Beam voltage E [1]	13 kV	Beam voltage E 13 - 15 kV
Beam voltage E [2]	15 kV	Beam voltage E 13 - 15 kV
Output POWer 't aenan	6 kW	Output POWER 't aenan 6 - - kW
Capacitance grid to all other electrodes	25 pF	Capacitance grid to all other electrodes - - 25 pF
Gridbiasvoltage oo	-100 V	Gridbiasvoltage oo -100
Heater warmuptimec [1]	0	Heater warmuptimec.000uus. 3
Heater warmuptimec [2]	3	Heater warmuptimec.000uus. 3

PARAMETER	PUBLISHED VALUE	CONDITION / NOTE
Heatervoltage [1]	0 V	Heatervoltage 7
Heatervoltage [2]	7 V	Heatervoltage 7
Operatingtemperature	-20	Operatingtemperature -20
Peak output power	0 W	Peak output power
Peak beamcurrent	0 mA	Peak beamcurrent
Gridbiasvoltage	0 V	Gridbiasvoltage
These operating instructions provide basic information for installing and operating the TV	9140	These operating instructions provide basic information for installing and operating the TV 9140 pulsed
Specified heater voltage should be applied for at least	3 V	Specified heater voltage should be applied for at least 3 minutes before applying beam voltage. Heater
surge current should never exceed	5 A	surge current should never exceed 5 amperes.
applied. An overvoltage relay should be provided to limit the beam voltage to	16 kV	applied. An overvoltage relay should be provided to limit the beam voltage to 16 kV dc.
difference between grid and cathode to a maximum of	500	difference between grid and cathode to a maximum of 500 volts.
A peak current sensing device should be employed which will limit the peak beam current to	4 A	A peak current sensing device should be employed which will limit the peak beam current to 4 A
Published value [1]	5	5. 6 cm and should connect to the collector end of the tube.
Published value [2]	6	5. 6 cm and should connect to the collector end of the tube.
The R.F. input and output connectors mates with a [1]	50	The R.F. input and output connectors mates with a 50 - Ohms coaxial, type "C", UG-573A/U plug or
The R.F. input and output connectors mates with a [2]	573	The R.F. input and output connectors mates with a 50 - Ohms coaxial, type "C", UG-573A/U plug or
VSWR of load is no more than [1]	2	VSWR of load is no more than 2. 0 : 1 throughout the operating frequency range.

PARAMETER	PUBLISHED VALUE	CONDITION / NOTE
VSWR of load is no more than [2]	0	VSWR of load is no more than 2. 0 : 1 throughout the operating frequency range.
VSWR of load is no more than [3]	1	VSWR of load is no more than 2. 0 : 1 throughout the operating frequency range.
Published value	5 V	5- APPLICATIONS OF VOLTAGES
– Apply heater voltage and allow at least	3 V	— Apply heater voltage and allow at least 3 minutes for cathode warm-up.
Published value [1]	159	15,9-22.2’91 RF OUTPUT CONNECTOR
Published value [2]	-22.2	15,9-22.2’91 RF OUTPUT CONNECTOR
Published value [3]	91	15,9-22.2’91 RF OUTPUT CONNECTOR
RF INPUT CONNECTOR ____ _?E;I [1]	190	RF INPUT CONNECTOR ____ _?E;I 19,0-25,4 Z’: DIA 4 HOLES
RF INPUT CONNECTOR ____ _?E;I [2]	-254	RF INPUT CONNECTOR ____ _?E;I 19,0-25,4 Z’: DIA 4 HOLES
RF INPUT CONNECTOR ____ _?E;I [3]	4	RF INPUT CONNECTOR ____ _?E;I 19,0-25,4 Z’: DIA 4 HOLES

TUBE TINKER

An independent reference for electronic tubes, vacuum tubes, and their source documents.

[Catalog](#) [Tube types](#) [Full books](#) [Blog](#) [Feedback & corrections](#)

© 2026 Tube Tinker