

improved 900W/010-210 burner



INSTRUMENT CATHODE RAY TUBE

*S_y 4.2
S_x 13.0*

BRIEF DATA

A short 10cm diagonal (4 in.) flat faced rectangular instrument tube with mesh p.d.a. This tube is intended for use in general purpose and portable oscilloscopes.

250 mm long

HEATER

Heater voltage	11	V
Heater current	68	mA

SCREEN

Fluorescence	Green
Phosphorescence	Green
Persistence	1-5ms
E.I.A. phosphor code	P31
Pro Electron phosphor code	GH
GEC phosphor code	24

Other screens are available to special order (see data sheet 'CRT Screens').

RATINGS (Absolute)

		Max	Min	
Fourth anode voltage	V_{a4}	7.0	2.0	kV
Third anode voltage	V_{a3}	1.0	0.5	kV
Ratio	V_{a4}/V_{a3}	10	2.0	
Focus voltage	V_{a2}	600	—	V
First anode voltage + mesh	$V_{a1} + \text{mesh}$	1.0	0.5	kV
Control grid voltage	$-V_{g1}$	200	1.0	V
Y plate to third anode voltage	V_{y-a3}	500	—	V
X plate to third anode voltage	V_{x-a3}	500	—	V
Grid to cathode circuit resistance	R_{g1-k}	1.0	—	MΩ
Y deflector plate circuit resistance	R_{y-a3}	100	—	kΩ
X deflector plate circuit resistance	R_{x-a3}	250	—	kΩ

Voltage ratings are to cathode unless otherwise shown.

CAPACITANCES (Typical)

Control grid to all other electrodes	9.3	pF
Deflector plates y1 to y2	2.0	pF
Deflector plates y1 to all electrodes except y2	5.0	pF
Deflector plates y2 to all electrodes except y1	5.0	pF
Deflector plates x1 to x2	2.5	pF
Deflector plates x1 to all electrodes except x2	7.0	pF
Deflector plates x2 to all electrodes except x1	7.0	pF

EQUIPMENT DESIGN RANGE

	Max	Min	
Focus voltage V_{a2}	400	233	V/kV a_3
Control grid voltage for spot cut-off $-V_{g1}$	140	50	V/kV a_1
Y deflection factor D_y	7.0	5.0	V/cm/kV a_3
X deflection factor D_x	21.7	17	V/cm/kV a_3
Astigmatism correction voltage $V_{a3-y \text{ mean}}$	+83	-83	V/kV a_3
Pattern correction voltage $V_{s-x \text{ mean}}$	+83	-83	V/kV a_3

TYPICAL OPERATION (All operating potentials are with respect to cathode)

Fourth anode voltage V_{a4}	6.0	kV
Third anode voltage V_{a3}	600	V
Focus voltage V_{a2}	140-250	V
First anode voltage + mesh $V_{a1} + \text{mesh}$	580	V
Control grid voltage for spot cut-off $-V_{g1}$	30-84	V
Nominal geometry correction voltage V_s	600	V
Maximum y deflection factor D_y	4.2	V/cm
Maximum x deflection factor D_x	13.0	V/cm
Line width (typical) 24 screen	0.4	mm

Measured by means of a shrinking raster at $I_b = 5\mu A$

DISPLAY CHARACTERISTICS (Typical Operation)

Pattern Distortion

With pattern correction applied to s, the edges of a test raster will lie between two concentric rectangles of 70mm x 50mm and 68mm x 48mm. The angle between x and y axes will be $90^\circ \pm 1^\circ$ measured at face centre.

X Deflection Linearity

The deflection factor for a deflection of less than 75% of the useful scan will be equal to that for a deflection of 25% within approx 3%.

Spot Position

The focused and undeflected spot will fall within a square 10mm x 10mm centred at the geometric centre of the faceplate.

Orientation

Looking at the screen with pins 1 and 12 uppermost, a positive voltage applied to x1 will deflect the beam to the left and a positive voltage applied to y1 will deflect the beam upwards.

Minimum Scanned Area

x major axis		7.0	cm
y minor axis		5.0	cm

This area will be centred on a point which is within 3mm of the major and minor axes of the tube face.

Axis Alignment

The electrical x axis of the tube will lie within $\pm 5^\circ$ of the major axis of the faceplate, and may be aligned with this axis by means of the field from an axial coil placed about the cone of the tube in the region shown in the outline drawing. The maximum ampere turns required for axis alignment will be given by $11\sqrt{kV_{a4}}$.

MOUNTING

The tube may be mounted in any position but should not be supported by the base alone. It should preferably be held in a suitable rubber mask at the screen and by a clamp around the magnetic shield near the base. The socket should have sufficient freedom of movement to accommodate the maximum overall tube length and base orientation tolerances.

WEIGHT

The weight of the tube alone is 500gm (approx).

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25

6: x1

12: a3 (astigmatism)

Side contact (CT8): a4

—

(clip) 10/425

Magnet shield
a twist coil

[illegible][illegible]

1

OUTLINE

1144

